

## STUDIO FLASH MONOLIGHT

### D-Lite RX ONE & 4

KIT



D-Lite RX ONE (20485.1.XX)  
- Flashtube (24009)



D-Lite RX ONE/ONE Softbox To Go (20847.2.XX)



D-Lite RX 4 (20487.1.XX)  
- Flashtube (24009)



D-Lite RX 4/4 Softbox To Go (20839.2.XX)

### ELC 125 & 500

KIT



ELC 125 (20618.1.XX)  
- Flashtube (24091)



ELC 500 (20619.1.XX)  
- Flashtube (24092)



ELC Dual 125/125 (20736.2.XX)



ELC Dual 125/500 (20762.2.XX)



ELC Dual 500/500 (20737.2.XX)

### ELC PRO HD 500 & 1000

KIT



ELC 500 Pro HD (20613.1.XX)  
- Flashtube (24084)



ELC 1000 Pro HD (20616.1.XX)  
- Flashtube (24084)



ELC Pro HD 500 To Go (20662.2.XX)



ELC Pro HD 1000 To Go (20663.2.XX)

## OFF CAMERA FLASH

### ONE

KIT



ONE (20932.1)  
- Flashtube (24091)



OCF Adapter (26346)



OCF Diffusion Dome (25110)



Power bank 20000 MAH 18W (11050)



ONE DUAL KIT (20931.2)  
- Flashtube (24091)




OCF Wide Reflector 16 cm (6.3") (26090)



EL-Profoto® Adapter (26345)



Charger 65W USB-C (11052)



OCF Barndoors (26002)



ONE Backpack (33252)

### ELB 500

KIT



ELB 500 TTL To Go (10309.1)



ELB 500 Head (20190)  
- Flashtube (24009)  
- Extension Cable 5 m (11003)



Q-Reflector Grid 18 cm (26056)



ELB 500 Battery (19297)



Q-Reflector Adapter MK1 (26342)



Q-Wide Reflector 13.5 cm (26145)



ELB 500 Charger (19277)



Q-Protective Cap (25101)



ELB 500 TTL Dual To Go (10310.1)

## BATTERY POWERED FLASH SYSTEM

### ELB 1200

KIT



ELB 1200 Hi-Sync To Go (10305.1.XX)



ELB 1200 Hi-Sync Head (20188)  
- Flashtube (24089)  
- Extension Cable 5m (11007)



Dock (19274)



ELB 1200 Hi-Sync To Roll (10315.1.XX)



Battery Charger (19278)  
Car Battery Charger (11038)



Battery Air 90 Wh (19273)  
Battery HD 144 Wh (19296)

## SOFTBOXES

### ROTALUX

**Rotalux Square**  
 70 cm (27") (26642)  
 External Diffuser (26721)  
 Rotagrid Square (26774)

**Rotalux Square**  
 100 cm (39") (26643)  
 External Diffuser (26722)  
 Rotagrid Square (26782)

**Rotalux Recta**  
 60 x 80 cm (23.6x31.5") (26640)  
 External Diffuser (26713)  
 Rotagrid Recta (26772)

**Rotalux Recta**  
 90 x 110 cm (35.5x43") (26641)  
 External Diffuser (26714)  
 Rotagrid Recta (26773)

**Rotalux Strip**  
 35 x 100 cm (14x39") (26644)  
 External Diffuser (26723)  
 Rotagrid Strip (26775)

**Rotalux Strip**  
 50 x 130 cm (20x51") (26645)  
 External Diffuser (26724)  
 Rotagrid Strip (26776)

**Rotalux Octa**  
 100 cm (39") (26646)  
 External Diffuser (26716)  
 Rotagrid Octa (26777)

**Rotalux Octa**  
 135 cm (53") (26647)  
 External Diffuser (26717)  
 Rotagrid Octa (26778)

**Rotalux Octa**  
 175 cm (69") (26649)  
 External Diffuser (26715)  
 Rotagrid Octa (26780)

**Rotalux Deep Octa**  
 70 cm (27.5") (26650)  
 External Diffuser (26702)  
 Rotagrid Octa (26781)

**Rotalux Deep Octa**  
 100 cm (39") (26648)  
 External Diffuser (26716)  
 Rotagrid Octa (26777)

**Rotalux Deep Octa Indirect**  
 150 cm (59") (26188)  
 External Diffuser (26703)  
 Rotagrid Indirect (26779)

### SPEEDRINGS FOR ROTALUX

Elinchrom (26559)  
 Bowers®/S Mount (26554)  
 Profoto® (26542)  
 Profoto® OCF (26547)  
 Broncolor® (26543)  
 Alienbee®/Balcar® (26545)

### LITEMOTIV

**Litemotiv Direct Para**  
 190 cm (75") (28005)

**Litemotiv Direct Para**  
 120 cm (47.3") (28004)

### LITEMOTIV BRACKET

Elinchrom® (26537)  
 Bowers® (26538)  
 Profoto® (26539)  
 Broncolor® (26540)

### LITEMOTIV INDIRECT

**Indirect Litemotiv Strip**  
 33 x 175 cm (13x69") (28003)

**Indirect Litemotiv Recta**  
 72 x 175 cm (28x69") (28002)

**Indirect Litemotiv Square**  
 145 cm (57") (28001)

**Indirect Litemotiv Octa**  
 190 cm (75") (28000)

## REFLECTORS & GRIDS

**Wide Reflector**  
 16 cm (6.3") (26170)

**Grid Reflector**  
 18 cm (7") (26081)

**Grid 18 cm (7")**  
 30° (26100)  
 20° (26101)  
 12° (26102)

**Standard Reflector**  
 21 cm (8.3") (26171)

**Grids 21 cm (8.3")**  
 8° (26055)  
 12° (26054)  
 20° (26053)  
 30° (26052)

**Barndoor 21 cm (8.3") Set** (26037)  
**Barndoor 21 cm (8.3") Pro Set** (26039)

**10 Colour Filter 21 cm (8.3")** (26243)  
**20 Advanced Colour Filters 21 cm (8.3")** (26256)

**Snoot & Grid**  
 15" (26061)

**Maxi Reflector**  
 40 cm  
 White (26161)  
 Silver (26162)

**High Performance Reflector**  
 26 cm (10.2") (26071)

**Background Reflector**  
 32 x 21 cm (12.5x8.3") (26066)

**Softlite Beauty Dish Reflector**  
 70 cm (27.6")  
 White (26070)  
 Silver (26068)

**Softlite White Beauty Dish**  
 44 cm (17.3")  
 White (26069)  
 Silver (26067)

**Softlite Beauty Dish Grid**  
 Grid 70 cm (26023)  
 Grid 44 cm (26021)

**Softlite Beauty Dish Diffusion Cap**  
 Softlite 70 cm (26235)  
 Softlite 44 cm (26232)

**Protective Cap MK-III** (27125)

**Protective Cap MK-II** (27124)

**Fresnel Spot 30** (26451)

**FS 30 Accessory Set** (26452)

**Deflector Kit** (26310)

**Grid Reflector & Grid Kit** 18 cm (7") (26060)

**Grid Reflector & Pro Grid Kit** 18 cm (7") (26135)

**Standard Reflector & Grid 21 cm Kit** (8.3") (26049)

**Standard Reflector Pro & Grid Kit** 21 cm (8.3") (26051)

**Softlite White Beauty Dish & Grid Kit** 44 cm (17.3") (26900)  
**Softlite Silver Beauty Dish & Grid Kit** 44 cm (17.3") (26901)

## UMBRELLAS

**Shallow Silver Umbrella**  
 105 cm (41") (26348)  
 85 cm (33") (26350)

**Shallow Translucent Umbrella**  
 105 cm (41") (26349)  
 85 cm (33") (26351)

**Umbrella Shallow White/Translucent**  
 105 cm (41") (26359)  
 85 cm (33") (26358)

**Deep Silver Umbrella**  
 105 cm (41") (26352)  
 125 cm (49") (26353)

**Deep White Umbrella**  
 105 cm (41") (26356)  
 125 cm (49") (26357)

**Deep Translucent Umbrella**  
 105 cm (41") (26354)  
 125 cm (49") (26355)

**Deep Black Diffuser**  
 105 cm (41") (26763)  
 125 cm (49") (26764)

**Deep Translucent Diffuser**  
 105 cm (41") (26761)  
 125 cm (49") (26762)

**ECO Umbrella Kit** (26062)

**Umbrella Portrait Kit** (26363)

**Umbrella To Go Kit** (26362)

## REMOTE CONTROLS

**TRANSMITTERS**

**Elinchrom Transmitter PRO**  
 Canon® (19366)  
 Sony® (19371)  
 Nikon® (19367)  
 Fujifilm® (19337)  
 Olympus® (19372)  
 Panasonic® (19372)  
 Pentax® (19336)

**RECEIVER**

**EL-Skyport Transmitter Plus** (19368)

**EL-Skyport Receiver Plus** (19369)

**COMPUTER AND iOS CONTROL**

**Elinchrom Bridge** (19338)

**EL-Skyport Universal Plus set** (19370)

## TRIPODS

**Tripod Air HD**  
 124-385 cm (31039)

**Tripod Air Click**  
 105-244 cm (31038)

**Tripod 88-235 cm** (30101)

**Boom Arm**  
 63-156 cm (31049)

**Tripod Set 2** (30162)

## BAGS

**Storage Bag** (33236)

**ProTec Location Bag** (33195)

**ProTec Rolling Case** (33188)

**ProTec Poly Bag** (33196)

**ProTec Bag Softlite 44 and 21** (33231)

**Grid Bag for 18 and 21** (33217)

**Hardshell Box** (33238)

**ONE Backpack** (33252)

**ONE Case** (33250)

**Tube case for D-Lite RX ONE** (33194)  
**D-Lite 4** (33198)